


# Operation Guide 5308/5309

CASIO®

- Your watch may differ somewhat from the one shown in the illustration.



## To adjust the time setting

When the second hand is at 12 o'clock, pull the **Crown** out to Click 2.

Rotate the **Crown** to change the time setting.

Push the **Crown** back in.

### Note

- When changing the time, move the minute hand four or five minutes past your final setting, and then back it up to the setting you want.

## To change the day and day of the week settings

Pull the **Crown** out to Click 1.

Rotate the **Crown** towards you to set the day.

Rotate the **Crown** away from you to set the day of the week.


Push the **Crown** back in.

### Note

- The day setting uses a 31-day month. Make adjustments for months of shorter lengths.
- Avoid changing the day and day of the week settings between the hours of 9 p.m. and 4 a.m. Otherwise, the day and day of the week may not change correctly at midnight.


## Crown Operations

Some water-resistant models (100 meters, 200 meters) have a screw-in crown. When you need to perform a crown operation, rotate it towards you to unscrew it. Then pull the crown out. Avoid applying undue force when pulling. The watch loses its water resistance while the crown is unscrewed. After performing a crown operation, fully screw the crown back in.



## If your watch has a rotary bezel...

You can rotate the bezel to align its ▼ mark with the minute hand. Then you will be able to tell how much time has elapsed since aligning the ▼ mark.



## Specifications

Module No.	Accuracy at normal temperature (per month)	Battery type	Battery life
5308	±20 seconds	SR716SW	Approx. 3 years
5309	±20 seconds	SR920SW	Approx. 3 years